

Fuselage Top

Pod Tray

Save pattern for canopy

canopy - cut from clear plastic
fold and clear tape

Glue wings together with 1.5" under each wingtip



exhaust stacks - paint black

servo tray

AA AA

OLD GUY RC
Focke Wulf 152 TA
2-3 Channel Control
40" span. 1.45 sqft
6oz all up weight



Focke Wulf 152 TA

1System Pod
Warbird

cut cardstock and roll
to make turbo charger

turbo charger

fuselage bottom

Build half of fuselage and lay 1System Pod in
and poke dowel thru. After completing fuselage
push dowel thru other side with pod in place

Join fuselage after making sure it is straight

popsicle stick
control horn 1/4 x 3/4"

fine music wire control rod
leave 1/2" below horn

half deep cuts on dashed lines

Cut slot in fuselage side for
control exit

dowel across
for rubber band
wing hold down

install pod, servo, controls before joining fuselage halves

coffee stir sticks taped together, tape to inside of fuselage

glue tail together
after making
sure fuselage is straight

