



bamboo skewer - poke through fuse and glue to underside of wing
Dab glue on after dihedral is set

Setting Wing Incidence on Biplanes:
Set both wings as measured to a line drawn across fuselage from stabilizer forward as a 0 degree reference. Now adjust stabilizer up or down just slightly to get a fairly flat glide with no stall tendency. The difference may be just 1-2 degrees.

Motor down thrust should be 2 degrees. If the plane refuses to climb lessen downthrust, if it climbs too much increase. Plane should climb under control with throttle, and land as throttle is decreased.



OLD GUY RC
Fokker D7
Rudder Only Control
27.5 span. 1.33 sqft
6 oz all up weight

Fokker D7

